

SURE[®] Cleaner & Degreaser

Heavy duty degreaser in SmartDose[™]

Description

SURE Cleaner & Degreaser is part of a unique range of plant based, 100% biodegradable professional cleaning products for all daily cleaning needs.

SURE Cleaner & Degreaser is a concentrated heavy duty degreaser for cleaning of all heavily soiled surfaces in the kitchens like equipment, cooker hoods and cooker tops, tables etc. It is also suitable for heavy duty cleaning of floors.

Key properties

- Suitable for cleaning of all heavily soiled surfaces
- Good wetting of surfaces
- No fragrance nor dye
- Contains plant based ingredients from renewable sources
- 100% biodegradable and decomposed by natural processes
- No environmental hazard classifications, no safety warnings for user

Benefits

- Concentrated formulation gives excellent economy in use
- Convenient and controlled dosing into a spray bottle or bucket through the SmartDose dosing system from Diversey Care
- Powerful formulation cuts through heavy grease and leaves clean and shiny surfaces
- Reduced environmental impact



SURE[®] Cleaner & Degreaser

Heavy duty degreaser in SmartDose[™]

Use instructions

SURE Cleaner & Degreaser is supplied in SmartDose dosing system for convenient and controlled dosing of the product into a spray bottle or bucket.

Spray cleaning:

1. Fill the 750 ml trigger bottle with water.
2. Turn yellow head to trigger bottle position: pull head up, then push down fully to dispense chemical. Shake bottle gently before use.
3. Remove debris before applying product.
4. Spray surface with solution and clean with damp cloth.
5. Rinse food contact surfaces with clean water and allow to air dry.

General bucket cleaning:

1. Start filling bucket with water.
2. Turn yellow head to trigger bottle position: pull head up, then push down. Dose once while filling bucket up to 3.5L. For higher level of soil dose twice while filling up to 5L.
3. Remove debris before applying product.
4. Apply solution and clean surfaces using cloth, brush or mop system.
5. Rinse food contact surfaces with clean water and allow to air dry.

Floor cleaning:

1. Start filling bucket with water.
2. Turn yellow head to bucket position: pull head up, then push down fully whilst filling bucket up to 15 L.
3. Remove debris before applying product.
4. Apply solution and clean surfaces using cloth, brush or mop system.
5. Rinse food contact surfaces with clean water and allow to air dry.

For very dirty surfaces apply solution and let the product act a couple of minutes before scrubbing the surface.

Technical data

Appearance:	colourless to pale yellow liquid
pH neat:	>11,5
Relative density (20°C):	1.02
Viscosity (20°C):	<50 mPa.s

These figures are typical values and should not be interpreted as specifications.

Safe handling and storage information

Full guidance on the handling and disposal of this product is provided in a separate Safety Data Sheet.

Only for professional users/specialists. Store in original closed containers away from extremes of temperature.

Product compatibility

Under recommended conditions of use, SURE Cleaner & Degreaser is suitable for use on all materials commonly encountered in kitchens, except soft metals like aluminium, copper or brass.

Environmental information

*SURE Cleaner & Degreaser formulation is 100% biodegradable according to OECD 301B test.

The surfactants used in this product are biodegradable in compliance with the requirement of EU Detergent Regulation, EC 648/2004.

EU Ecolabel registration is pending.

www.sealedair.com

Mini Guide – SURE® Cleaner & Degreaser

Available in 1.4 L SmartDose



Low foaming
cleaner &
degreaser




Heavy duty
floor cleaning




Heavy duty
degreaser

Use for cleaning:



Polished and
unpolished floors



Floors
and walls



Cooker tops



Cooker hoods



General kitchen
equipment

Using...

1



Large bucket/machine cleaning:
(Floor cleaning)

Turn yellow pump to large bucket
icon. Pull up pump until ratchet stops,
press once into 15 litres of water
Spray bottle & Small bucket
(Surface cleaning):


Turn yellow pump to trigger / small
bucket icon. Pull up pump until
ratchet stops, press once into 750ml
trigger bottle or once into a small
bucket filled with 3.5L water.

2



Remove debris
before applying
product.
Using cloth, mop or
machine to apply
solution

3



Apply solution using cloth/mop/
spray. Clean with cloth, brush or
mop.
Rinse cloth / mop out regularly.

4



For Building Care
application:
Allow to air dry
For Kitchen Care
application:
Rinse surface with
clean water. Allow
to air dry.

